



Intake Screen 5-Step Quick Install Guide



Step 1: Bolt Screen

- Bolt two screen pieces together as shown and repeat with other two pieces.



Step 2: Bolt All Pieces Together

- Bolt two previous sections together to finish intake screen as shown.



Step 3: Place Float

- Place float on top of intake screen and install eye bolts for mooring ropes in opposite corners.



Step 4: Install

- Install bolts in remaining two opposite corners to secure intake screen to float.



Step 5: Lower Fountain or Aerator

- You are now ready to lower your fountain or aerator into the float.

*See fountain or
aerator quick
install guide*





ARBRUX
MANUFACTURING

Enjoy the Extra Protection of an
Arbrux Intake Screen!